

- 1. A & B Search and Secure Muon Alcoves 4, 3, 2 and reset door boxes SS#1.
- 2. A & B Sweep Absorber Room and reset gate box, SS#1.
- 3. A Waits while B sweeps the RAW Skid area and resets SS #2.
- 4. A & B exit Absorber area and reset SS#3.

G. Lauten, AD Rad Safety

January 31, 2005